

# QUICK START GUIDE

## SecurityKeypad™

Once you have logged into your Virtual Keypad App™ and plugged in your SecurityGateway™, use this guide to set up your keypad.

### 1 ATTACH THE DESKSTAND

The keypad is designed to be placed on a tabletop or other flat surface.

1. Press the slide lock on one of the stand legs into the square opening located on the back of the case.
2. Slide the leg upward until the top ridge seats.
3. Repeat the process to attach the second side of the deskstand.

### 2 POWER IT UP


1. Plug the USB end of the cable into the power supply adapter.
2. Plug the power supply adapter into an outlet not controlled by a switch.
3. Plug the micro USB end of the cable into the back of your keypad.

### HAVE QUESTIONS?


See your SecurityGateway™ System User Guide or contact your security system provider.

LT-1477 16325







PAIRING SCREEN



HOME SCREEN



NO COMMUNICATION SCREEN



RESET SCREEN

### 3 AUTO PAIR

When you power your keypad and gateway, the auto pairing process begins immediately and a 10-minute auto pairing timer starts. The keypad automatically displays **Pairing Keypad With System**.

If the gateway acquires the keypad during the 10-minute auto pairing time period, you will see the home screen display on the keypad, signaling that pairing is complete.

If the gateway does not acquire the keypad by the end of the pairing timer, the keypad displays **Pairing Failed**, followed by the Reset screen.

Press the RESET button on the hub and the **Pair** button on the keypad to restart the pairing process.

If the keypad loses communication with the panel, the **No Communication With System** display appears and gives you the option to reattempt pairing.

### 4 CONTINUE TO THE NEXT STEP

Refer back to your Virtual Keypad App™ and press Continue.

#### HAVE QUESTIONS?

See your SecurityGateway™ System User Guide or contact your security system provider.

