




**MAGNET**



**SENSOR**



**FLAT FRAME**



**CURVED FRAME**

# QUICK START GUIDE

## SecuritySensor™ Door

Once you have logged into your Virtual Keypad App™ and plugged in your keypad, use this guide to connect your door sensor.

### 1 PLACE THE SENSOR

#### FLAT FRAME

Remove the double-sided tape backing from the sensor and place it above the edge of the door jamb with the rounded part of the sensor on the bottom. Remove the double-sided tape backing from the magnet and place it on the door directly below the sensor. They should be no more than a half-inch apart.

#### CURVED FRAME

Remove the double-sided tape backing from the sensor and place it below the edge of the door jamb with the rounded part of the sensor on the top. Remove the double-sided tape backing from the magnet and place on the frame directly above the sensor. They should be no more than a half-inch apart.

### 2 CONTINUE TO THE NEXT SENSOR

Continue installing the rest of your sensors, then select the Continue button on the Virtual Keypad App™ to add a user code and complete the installation.

#### HAVE QUESTIONS?

See your SecurityGateway™ System User Guide or contact your security system provider.

LT-1479 16325

