



QUICK START GUIDE

SecuritySensor™ Window

Once you have logged into your Virtual Keypad App™ and plugged in your keypad, use this guide to connect your window sensor.

- 1 PLACE THE SENSOR**

Remove the double-sided tape backing from the sensor and place it on the window frame with the marked side of the sensor towards the window.
- 2 PLACE THE MAGNET**

Remove the double-sided tape backing from the magnet and place it on the window, centering the magnet marker on the sensor marker. Leave no more than a half-inch between the sensor and the magnet.
- 3 CONTINUE TO THE NEXT SENSOR**

Continue installing the rest of your sensors, then select the Continue button on the Virtual Keypad App™ to add a user code and complete the installation.

HAVE QUESTIONS?

See your SecurityGateway™ System User Guide or contact your security system provider.

LT-1480 16325

