

XR5FC/XR5SL PROGRAMMING SHEET

Name _____ Account Number _____ Date _____

Address _____ City _____ State _____ Zip _____

COMMUNICATION

Communication Type NONE **DD** CID
 2nd Phone Line NO **YES**
 Account Number - - - - - (DD range = 1 to 65535)
 (CID range = 1 to 9999)

DTMF NO **YES**

Receiver 1

Alarm NO **YES**
 Supv/Trouble NO **YES**
 Test Report NO **YES**
 Backup **NO** YES

First Phone No. - - - - -

Second Phone No. - - - - -

Receiver 2

Pager **NO** YES
 Alarm **NO** YES
 Supv/Trouble **NO** YES
 Test Report **NO** YES
 Backup **NO** YES

First Phone No. - - - - -

Second Phone No. - - - - -

Pager ID Number - - - - -

REMOTE OPTIONS

Remote Key - - - - -
 Manufacturer Auth **NO** YES
 Armed Rings - - (0 to 15, default = 0)
 Alarm Receiver **NO** YES
 Service Receiver NO **YES**

SYSTEM OPTIONS

Cross Zone Fault Time - - - (0, 4 to 250 seconds, default = 0)
 Zone Retard Delay - - - (0 to 250 seconds, default = 0)
 Power Fail Delay - - (0 to 15 hours, default = 1)
 Reset Swinger Bypass NO **YES**

OUTPUT OPTIONS

Bell Cutoff Time - - (0 to 15 minutes, default = 15)
 Bell Action . . .
 Fire Zones Steady **Pulse** Temporal CA None
 Supervisory Zones Steady Pulse Temporal CA **None**
 Auxiliary 1 Zones Steady Pulse Temporal CA **None**
 Output Action . . .
 Cutoff Output 1 2 3 4
 Cutoff Time - - (0, 1 to 15 minutes, default = 0)
 (Select at least one Cutoff Output)
 Comm Fail Output - (0 to 4, default = 0)
 Fire Alarm Output - (0 to 4, default = 0)
 Fire Trouble Output - (0 to 4, default = 0)

Note: Default values are in **bold** type.

XR5FC/XR5SL ZONE PROGRAMMING

Zone Information	Type	Open			Short			Swinger Bypass	Retard Delay	Cross Zone
		Message	Output	Action	Message	Output	Action			
Use this section of the programming sheet to record the program options you selected for the XR5 panel zone.	FI									
	SV									
	A1	A	0	S	A	0	S	N	N	N
	FV	T	to 4	P M F	T	to 4	P M F	or Y	or Y	or Y
Fire	FI	T	0	-	A	0	-	N	N	N
Supervisory	SV	T	0	-	A	0	-	N	N	N
Auxiliary 1	A1	T	0	-	A	0	-	N	N	N
Fire Verify	FV	T	0	-	A	0	-	N	N	
No.	Zone Name									
1										
2										
3										
4										
5										
31										
32										
33										
34										

