

NETWORK OPTIONS (XR500N/XR500E only)

DHCP NO YES
 Local IP Address - - - - -
 Gateway Address - - - - -
 Subnet Mask - - - - -
 DNS Server - - - - -
 Passphrase (XR500E) - - - - -
 734N Listen Port - - - - - (Default = 2002)
 734N Passphrase - - - - -

DEVICE SETUP

#	Device		Device Name	Wireless?	Serial Number	Supervision Time (0, 60, 240)	Access Areas (1-32)	Egress Areas (1-32)	Display Areas (1-32)	Strike Time (0-250 sec)	Strike Delay (0-9 min)	Fire Exit	Output Group	Over-ride	Auto Force Arm	Door Real Time	Door Force Msg
	Type	Comm. Type															
	DOOR KPD FI EXP	KPD-BUS NETWORK WIRELESS		N Y								N Y	N Y	N Y	N Y	N Y	N Y
	DOOR KPD FI EXP	KPD-BUS NETWORK WIRELESS		N Y								N Y	N Y	N Y	N Y	N Y	N Y
	DOOR KPD FI EXP	KPD-BUS NETWORK WIRELESS		N Y								N Y	N Y	N Y	N Y	N Y	N Y
	DOOR KPD FI EXP	KPD-BUS NETWORK WIRELESS		N Y								N Y	N Y	N Y	N Y	N Y	N Y
	DOOR KPD FI EXP	KPD-BUS NETWORK WIRELESS		N Y								N Y	N Y	N Y	N Y	N Y	N Y
	DOOR KPD FI EXP	KPD-BUS NETWORK WIRELESS		N Y								N Y	N Y	N Y	N Y	N Y	N Y
	DOOR KPD FI EXP	KPD-BUS NETWORK WIRELESS		N Y								N Y	N Y	N Y	N Y	N Y	N Y
	DOOR KPD FI EXP	KPD-BUS NETWORK WIRELESS		N Y								N Y	N Y	N Y	N Y	N Y	N Y
	DOOR KPD FI EXP	KPD-BUS NETWORK WIRELESS		N Y								N Y	N Y	N Y	N Y	N Y	N Y

DEVICE SETUP (continued)

#	734 Option	Zone 2 Activate Bypass	Zone 2 Bypass Time (20-240)	Relock on Zone 2 Change?	Activate Zone 3 Rex?	Zone 3 Strike Time? (5-250)	Zone 3 Rex Strike Time? (5-250)	Activate Onboard Speaker?	Card Options	Wiegand Code Length (1-255)	Site Code Position (0-255)	Site Code Length (1-16)	User Code Position (0-255)	User Code Length (734: 16-32) (734N: 1-255)	Require Site Code?	Site Code Up to 8 Codes (734: 0-999) (734N: 1-65535)	No of User Code Digits (734: 4-10 digits) (734N: 1-10)	No Communication with Panel
	N Y	N Y		N Y	N Y			N Y	DMP CUSTOM ANY						N Y			
	N Y	N Y		N Y	N Y			N Y	DMP CUSTOM ANY						N Y			
	N Y	N Y		N Y	N Y			N Y	DMP CUSTOM ANY						N Y			
	N Y	N Y		N Y	N Y			N Y	DMP CUSTOM ANY						N Y			
	N Y	N Y		N Y	N Y			N Y	DMP CUSTOM ANY						N Y			
	N Y	N Y		N Y	N Y			N Y	DMP CUSTOM ANY						N Y			
	N Y	N Y		N Y	N Y			N Y	DMP CUSTOM ANY						N Y			
	N Y	N Y		N Y	N Y			N Y	DMP CUSTOM ANY						N Y			
	N Y	N Y		N Y	N Y			N Y	DMP CUSTOM ANY						N Y			

MESSAGING SETUP

Enable Messaging **NO** YES
 System Name _____
 Destination 1 _____
 Destination 1 User Number - - - - -
 Destination 2 _____
 Destination 2 User Number - - - - -
 Destination 3 _____
 Destination 3 User Number - - - - -
 Email Comm Type **NET** CELL
 O/C Email **NO** YES
 O/C SMS **NO** YES
 Monthly Limit - - - - (0-999, Default = 0)
 SMTP Server _____
 SMTP Port - - - - -
 SMTP Username _____
 SMTP Password _____
 From Email _____

REMOTE OPTIONS

Remote Key - - - - -
 Remote Disarm **NO** YES
 Armed Answer Rings - - (0 to 15, default = 8)
 Disarmed Answer Rings - - (0 to 15, default = 8)
 PC Modem **NO** YES
 Alarm Receiver Auth **NO** YES
 Service Receiver Auth NO **YES**
 Manufacturer Auth **NO** YES
 Allow Network Remote NO **YES**
 Network Programming Port - - - - (Default = 2001)
 Encrypt Network Remote **NO** YES
 Allow Cellular Remote NO **YES**
 First GPRS APN - - - - -
 (Default = NMRX.CA.APN)
 Second GPRS APN - - - - -
 (Default = INTERNET.COM)
 Encrypt Cellular Remote **NO** YES
 Allow RS-232 Remote NO **YES**
 Entre Connection **NONE** NET
 Entre Incoming TCP Port - - - - (Default = 2011)
 Entre IP Address - - - - -
 Entre Outbound TCP Port - - - - (Default = 2001)
 Entre Backup IP Address - - - - -
 Entre Backup TCP Port - - - - (Default = 2001)
 Entre Checkin Minutes - - - (0, 3-240 minutes, default = 0)
 Entre Passphrase - - - - -
 Send Local Changes **NO** NET DD
 Remote Change IP - - - - -
 Remote Change Port - - - - (Default = 2002)
 Remote Phone No - - - - -

SYSTEM REPORTS

Abort Reports **NO** YES
 Restoral Reports NO **YES** DISARM
 Bypass Reports NO **YES**
 Schedule Change Rpts NO **YES**
 Code Change Reports NO **YES**
 Access Keypads **1 2 3 4 5 6 7 8**
9 10 11 12 13 14 15 16
 Ambush **NO** YES

SYSTEM OPTIONS

	AREA	A/P	H/A	GST
System	NO	YES		
Instant Arming	NO	YES		
Closing Wait	NO	YES		
Entry Delay 1	- - - -	(30 to 250 sec, default = 30)		
Entry Delay 2	- - - -	(30 to 250 sec, default = 60)		
Entry Delay 3	- - - -	(30 to 250 sec, default = 90)		
Entry Delay 4	- - - -	(30 to 250 sec, default = 120)		
Cross Zone Time	- - - -	(4 to 250 sec, default = 4)		
Zone Retard Delay	- - - -	(0 to 250 sec, default = 10)		
Power Fail Delay Hrs	- - - -	(0 to 15 hours, default = 1)		
Swinger Bypass Trips	- - - -	(0 to 6, default = 2)		
Reset Swngnr Bypass	NO	YES		
Time Change	NO	YES		
Hours from GMT	- - - -	(0 to 23, default = 6)		
Latch Supervisory	NO	YES		
Programming Language				
Primary Language	ENGLISH	SPANISH	FRENCH	
Secondary Language	NONE	ENG	SPN	FRN
User Language				
Primary Language	ENGLISH	SPANISH	FRENCH	
Secondary Language	NONE	ENG	SPN	FRN
Bypass Limit	- - - -	(0 to 8, default = 0)		
Card Plus PIN (XR500E)	NO	YES		
Wireless House Code	- - - -	(0, 1 to 50, 99, default = 0)		
Detect Wireless Jamming	NO	YES		
Wireless Audibles	ANY	DAY	MIN	
Enable Keypad Panic Keys	NO	YES		
Occupied Premise	NO	YES		
Enhanced Zone Test	NO	YES		
Send 16 Character Names	NO	YES		
Keypad Armed LED	ALL	ANY		
Use False Alarm Question	NO	YES		
Change Own User Code	NO	YES		
Panic Supervision	NO	YES		

BELL OPTIONS

Bell Cutoff Time - - - - (0 to 99 minutes, default = 15)
 Automatic Bell Test **NO** YES
 Bell Output - - - -
Bell Action . . .
 Fire Zones Steady **Pulse** Temporal None
 Burglary Zones **Steady** Pulse Temporal None
 Supervisory Zones Steady Pulse Temporal **None**
 Panic Zones Steady Pulse Temporal **None**
 Emergency Zones Steady Pulse Temporal **None**
 Auxiliary 1 Zones Steady Pulse Temporal **None**
 Auxiliary 2 Zones Steady Pulse Temporal **None**

OUTPUT OPTIONS

Cutoff Output 1 2 3 4 5 6
 Cutoff Time - - - - (0 to 99 minutes, default = 0)
 Comm Fail Output - - - -
 Fire Alarm Output - - - - Phone Trouble Output - - - -
 Fire Trouble Output - - - - Late to Close Output - - - -
 Panic Alarm Output - - - - Device Fail Output - - - -
 Ambush Output - - - - Sensor Reset Output - - - -
 Entry Output - - - - Closing Wait Output - - - -
 Exit Output - - - - Arm-Alarm Output - - - -
 Ready Output - - - - Supv Alarm Output - - - -

