

SCS-IR PROGRAMMING SHEET

Name _____ Date _____

Address _____ City _____ State ____ Zip _____

Operator Codes

Operators 1 and 2 have default Operator Name, Operator Code, and Level numbers assigned. These defaults can be changed as needed.

Operator #	Operator Name (1 to 4 Alphanumeric)	Operator Code (1 to 8 Alphanumeric)	Level (1 to 9-see table below)	Employee Name
1	NEW	NEW	9	Default
2	DFLT	99	9	Default
1	-----	-----	---	_____
2	-----	-----	---	_____
3	-----	-----	---	_____
4	-----	-----	---	_____
5	-----	-----	---	_____
6	-----	-----	---	_____
7	-----	-----	---	_____
8	-----	-----	---	_____
9	-----	-----	---	_____
10	-----	-----	---	_____

Operator Function	No Code	Level 1 to 4	Level 5 to 7	Level 8	Level 9
Acknowledge Alarms	X	X	X	X	X
Signon		X	X	X	X
Signoff		X	X	X	X
View Off-Normal Zone & Accounts		X	X	X	X
Set System Time/Day/Date			X	X	X
View System Status			X	X	X
Delete Off-Normal Zone & Accounts				X	X
Configure System				X	X
Host Automation				X	X
Change Operator Codes					X
Change Line Setup					X

Configure System

Company Name 1 _____ (up to 16 Alphanumeric characters)

Company Name 2 _____ (up to 16 Alphanumeric characters)

System Number ____ (0 to 9 - Default = 0)

Receiver Key _____ (1 to 8 Alphanumeric characters)

Line #	Line Type NONE NET - Default = Line 5 DD - Default = Line 1-4
1	NET DD
2	NET DD
3	NET DD
4	NET DD
5	NET DD



Host Automation

Test Interval	__ __	(1 to 60 minutes - Default = 1)
Acknowledge Timeout	__ __	(1 to 15 seconds - Default = 3)
Line Number Length	__ __	(0 to 2 ASCII characters - Default = 0)
Zone Number Length	__	(2 to 4 - Default = 3)
User Number Length	__	(2 to 4 - Default = 4)
Baud Rate	__ __ __ __	(300, 600, 1200, 2400, 4800, 9600 , 19200)
Start Character	__ __ __ __	(NONE, STX)
Area Format Decimal?	NO	YES
Retries to Failure	__ __	(1 to 15 - Default = 5)
Serial 3 Messages?	NO	YES
SCS-1R Printer Disable	NO	YES
SCS-1R Print Always?	NO	YES
CRC Error Check	NO	YES
Sequence Number	NO	YES
Small "z" Zone Messages?	NO	YES
SCS-1R Time to Panels	NO	YES
SCS-1R Hours from GMT	__ __	(0 to 23 - Default = 6)
Dialer Line Card Monitor?	NO	YES

Note: Default values are in bold type.