XF6 SERIES PANELS
Operating Instructions

NORMAL STANDBY CONDITION
When the system is in the normal standby condition, the keypad shows a blank display.

ALARM CONDITION
When the system is in an alarm condition, the keypad displays in red and shows the violated zone name(s) followed by an alarm display.

ALARM SILENCE
To silence the alarm while the bell or siren is sounding, enter your user code and press the **CMD** key. This silences the alarm but does not cancel any alarm reports to the central station.

RESETTING DETECTORS
To reset a smoke or other detector, after silencing, select **RESET** on the carosel menu and enter your user code. If using a 630F Remote Annunciator with keyswitch enabled, press the **RESET** button on the left side of the keypad. The keypad displays **SENSORS OFF** for five seconds followed by **SENSORS ON**. The keypad automatically exits the User Menu.

TROUBLE CONDITION
When a device is in a trouble condition, the keypad tones and displays the zone or device name followed by **TRBL**. Enter your user code to silence.

SYSTEM TESTING
In accordance with NFPA 72, you should test the fire system weekly to ensure proper operation. If your user code allows, you can do this through a function in the User Menu. After entering the User Menu, press the **CMD** key until **SYSTEM TEST?** displays. Press the left most top row Select key. The system bell, battery, and communication to the central station receiver system is then tested.

ALARM SERVICE
If service is required for this system, please contact:

Company _____

Address _____

Telephone _____

The operating instructions above should be attached to the front, or framed, and located adjacent to the panel or a keypad with an alphanumeric display.